

Installation instructions

For set # 5.5128 & 5.5129
66-69 B-Body & 67-72 A-Body

ENERGY
SUSPENSION®

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2008 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Energy suspension recommends that you read the installation instructions before you start.

(Before removing sway-bar and brackets, mark orientation of brackets appropriately for reinstallation.)

1. Remove sway-bar and brackets from vehicle.
2. Secure sway-bar in vise, remove old bushings from bracket and bar. (**Note: if bracket is bent, straighten and deburr bracket so that the bracket inside surface is a rough copy of the bushing outer surface.**)
3. After putting the bracket back on the sway bar with the correct orientation, Lubricate the end-link eyelet leading edge and the new bushing inside diameter.(dishsoap,motor oil,etc.),
4. Slide the bushing over the end-link eyelet and position the bushing just past the eyelet where the sway bar diameter is the smallest (**FIG 1**).
5. Lubricate (dishsoap, motor oil, spray lube etc..) the outer bushing edges that are facing the bracket as well as the bracket leading edges.
6. Slide the bracket over the bushing edges so that only the bushing center hump is keeping the bracket from sliding on completely.
7. With a set of channel-lock pliers, press the triangular bushing in by squeezing the bushing in one side at a time (**FIG 2**).
8. Slide the bracket and bushing to approximately 1" from the finished bushing pivot point. Apply the supplied grease to the sway-bar where the bushing will ride. Position bushing and bracket on top of grease.
9. Once the brackets and bushings are properly positioned you may reinstall the sway-bar assembly.
10. Retorque all bolts to factory specifications.

FIG. 1



FIG. 2



Note: If your O.E. brackets are beyond repair, Energy Suspension offers replacement adaptor brackets. These adaptor brackets allow you to use our greaseable sway-bar bushings and are offered in many different sizes.